

dLAN® 550+ WiFi



Manual

devollo

devolo dLAN[®] 550+ WiFi

© 2019 devolo AG Aachen (Deutschland)

While the information in this manual has been compiled with great care, it may not be deemed an assurance of product characteristics. devolo shall be liable only to the degree specified in the terms of sale and delivery.

The reproduction and distribution of the documentation and software supplied with this product and the use of its contents is subject to written authorization from devolo. We reserve the right to make any alterations that arise as the result of technical development.

Trademarks

Android™ is a registered trademark of Open Handset Alliance.

Linux® is a registered trademark of Linus Torvalds.

Ubuntu® is a registered trademark of Canonical Ltd.

Mac® and Mac OS X® are registered trademarks of Apple Computer, Inc.

iPhone®, iPad® and iPod® are registered trademarks of Apple Computer, Inc.

Windows® and Microsoft® are registered trademarks of Microsoft, Corp.

Wi-Fi®, Wi-Fi Protected Access™, WPA™, WPA2™ and Wi-Fi Protected Setup™ are registered trademarks of the Wi-Fi Alliance®.

devolo, dLAN® and the devolo logo are registered trademarks of devolo AG.

The firmware package from devolo contains files which are covered by different licenses, in particular under devolo proprietary license and under open source license (GNU General Public License, GNU Lesser General Public License or FreeBSD License). The source code which is available for Open Source distribution can be requested in writing from gpl@devolo.de.

All other names mentioned may be trademarks or registered trademarks of their respective owners. Subject to change without notice. No liability for technical errors or omissions.

devolo AG

Charlottenburger Allee 67

52068 Aachen

Germany

www.devolo.com

Version 1.1_3/19

Contents

1	Preface	5
1.1	About this manual	5
1.2	Intended use	6
1.3	CE Conformity	7
1.4	Safety notes	7
1.5	devolo on the Internet	9
2	Introduction	10
2.1	What exactly is dLAN?	10
2.2	What is WLAN?	10
2.2.1	Wi-Fi or WLAN?	11
2.3	What exactly is range+?	11
2.4	What does WiFi Clone mean?	11
2.5	The dLAN 550+ WiFi	11
2.5.1	PLC button	12
2.5.2	WiFi button	14
2.5.3	Network jack	16
2.5.4	Reset	16
2.5.5	WiFi antennas	16
2.5.6	Integrated electrical socket	16
3	Initial use	17
3.1	Package contents	17
3.2	System requirements	17
3.3	Connecting the dLAN 550+ WiFi	17
3.3.1	Starter Kit – Setting up a new dLAN network	18
3.3.2	Addition – Expanding an additional network	18
3.4	Installation of devolo software	20
3.5	Removing the adapter from the network	21

4	Network configuration	22
4.1	Calling up the built-in web interface	22
4.2	General information about the menu	22
4.3	Overview	25
4.4	WiFi	26
4.4.1	Status	27
4.4.2	WiFi networks	27
4.4.3	Guest network	29
4.4.4	Mesh	30
4.4.5	Schedule control	33
4.4.6	Parental control	34
4.4.7	WiFi Protected Setup (WPS)	36
4.4.8	Neighbour networks	39
4.5	Powerline	40
4.5.1	Add device	43
4.6	LAN	44
4.6.1	Status	44
4.6.2	IPv4 configuration	44
4.7	System	45
4.7.1	Status	45
4.7.2	Management	45
4.7.3	Configuration	47
4.7.4	Firmware	48
4.7.5	Config Sync	48
5	Appendix	49
5.1	Frequency range and transmitting power	49
5.2	Channels and carrier frequencies	49
5.3	Bandwidth optimization	50
5.4	Disposal of old devices	50
5.5	Warranty conditions	51

1 Preface

Thank you for placing your trust in this dLAN 550+ WiFi.

The dLAN 550+ WiFi allows you to set up your own home network with almost no effort. Because the clever dLAN technology transmits the data over the household electrical wiring, you do not have to lay any new cables.





1.1 About this manual





Carefully read all instructions before setting up the device and store the manual and/or installation guide for later reference.

After a brief introduction to dLAN® and WiFi basics and an introduction to the dLAN 550+ WiFi in Chapter 2, Chapter 3 tells you how to successfully start using the adapter in your network. Chapter 4 describes in detail the setting options of the built-in configuration interface and thus also access to the WiFi. Tips for bandwidth optimisation, information about product safety and environmental compatibility of the device, as well as our warranty terms, can be found in Chapter 5 at the end of the manual.

Description of the icons

This section contains a brief description of the icons used in this manual and/or on the rating plate, the device connector, as well as the icons used on the package:

Icon	Description
	Very important safety symbol that warns you of imminent electrical voltage which if not observed can result in serious injury or death.
	An important safety symbol that warns you of a potentially dangerous situation involving a burn hazard which can result in minor injuries or damage to property.
	An important note that should be observed which can potentially lead to material damages.
	The device may only be used indoors in dry conditions.

Icon	Description
	The manufacturer/distributing company uses the CE marking to declare that the product meets all applicable European regulations and has been subjected to the prescribed conformity assessment procedures.
	It is used to prevent the occurrence of waste electrical and electronic equipment and to reduce this type of waste through reuse, recycling and other forms of utilisation. The European Community WEEE Directive establishes minimum standards for handling waste electrical and electronic equipment in the EU.
	Additional information, background material and configuration tips for your device.
	Indicates a completed course of action

1.2 Intended use

Use devolo products, devolo software and the provided accessories as described to prevent damage and injury.

Products

devolo products are communication devices designed for indoors.* Depending on the product, they are equipped with a **PLC-** (PowerLine Communication) and/or a Wi-Fi module. Computers, laptops, smartphones, tablets, smart TVs and other devices connected this way are integrated into a home network over the existing electrical wiring and/or Wi-Fi without any complicated wiring. devolo devices must never be used outdoors because the high temperature fluctuations and moisture can damage both the product and the power line. devolo products may not be installed at a height above **two metres** unless an additional fastening mechanism is available. The products are intended for operation in the EU, Switzerland and Norway.

* The only exceptions are devolo outdoor products, which are suited for the outdoor use thanks to their IP certification.

Software

devolo devices can be used only with the free, downloadable programs approved and available on devolo AG's website (www.devolo.com) and in app stores (iOS and Google Play). Any modifications to the product-specific firmware or software could damage the products and, in the worst-case scenario, render them unusable and negatively affect conformity.

Always use the most up-to-date software version to make sure you have the latest security functions and device updates. The installed devolo software notifies you automatically if a new software version is available.

Accessories

Use only the provided accessories.

1.3 CE Conformity

CE This product complies with the technical requirements of the directives **2014/53/EU**, **2011/65/EU** und **2009/125/EC**.

This product is designed for use in the EU, Switzerland and Norway.

A printout of the simplified CE declaration of this product is separately included and can also be found under www.devolo.com/support/ce.

1.4 Safety notes

It is essential to have read and understood all safety and operating instructions before the devolo device is used for the first time; keep them safe for future reference.



DANGER! Electrical shock caused by electricity

Do not reach into the electrical socket, do not open the device and do not insert any objects into the electrical socket or into the ventilation openings

Users do not need to carry out any maintenance on devolo devices. In the event of damage, disconnect the devolo device from the mains supply by pulling it or its plug out of the electrical socket. Then contact qualified specialist personnel (after-sales service) exclusively. **Damage** is deemed to have occurred, for example,

- if the power plug is damaged.
- if the devolo device has been showered with liquid (such as rain or other water).

- if the devolo device is inoperable.
- if the housing of the devolo device is damaged.
 - *Do not plug devolo devices directly into each other. Devices that are plugged into each other can experience a decrease in transmission rate.*



DANGER! Electric shock caused by electricity

Device must be plugged into a power socket with a connected earth wire

devolo devices may be operated only on a **mains power supply** as described on the **rating plate**.

To disconnect devolo devices from the mains supply, unplug the device from the electrical socket.

The power socket and all connected network devices should be easily accessible so that you can pull the power plug quickly if needed.



CAUTION! Heat development during operation

Certain housing components can become very hot in certain situations. Attach device so that it is touch-proof, observing optimal positioning

devolo devices should only be installed at locations that guarantee adequate ventilation. Slots and openings on the housing are used for ventilation:

- **Do not cover** devolo devices during operation.
- Do not place **any objects on** devolo devices.
- Do not insert **any objects** into the **openings** of devolo devices.
- devolo devices must **not** be placed directly **next to** a naked **flame** (such as fire or candles).
- devolo devices must **not be exposed to direct heat radiation** (e.g. radiator, direct sunlight).



CAUTION! Damage to housing from cleaning agents containing solvents
Clean only electroless and with dry cloth

1.5 devolo on the Internet

For detailed information on our products, devolo dLAN and devolo Magic, visit www.devolo.com.

There you will find product descriptions and documentation, and also updates of devolo software and your device's firmware.

If you have any further ideas or suggestions related to our products, please don't hesitate to contact us at support@devolo.com!

2 Introduction

dLAN is an intelligent, secure technology that lets you set up a home network easily, quickly and economically via your household electrical wiring, without the need for complex and expensive dedicated cabling.



Fig. 1 devolo dLAN and WiFi throughout the home

2.1 What exactly is dLAN?

dLAN (**d**irect **L**ocal **A**rea **N**etwork) uses the household power grid to transfer data between computers equipped with suitable adapters and other network components. As a result, any power outlet can be used as a network access point. The data is modulated prior to transfer and sent as a signal via household power lines. State-of-the-art technology ensures that the power and data networks do not interfere with one another. Networking via dLAN is fast and secure. The data is encrypted using a key to prevent interception by third parties.

2.2 What is WLAN?

WLAN (**W**ireless **L**ocal **A**rea **N**etwork) refers to the use of radio technology to network computers and other devices. While it is possible to wirelessly connect computers in pairs (peer-to-peer, p2p), a central access point is required to set up a network of multiple devices. Such access points are frequently combined in a single device with modems for Internet access and routers to manage network traffic.

The wireless network established by an access point using a specific channel (from 1 to 13) and name (SSID) has a limited range. The range of the

access point, which is also known as a "radio cell", is impeded by building walls. In some cases, stable connections are often only possible between WLAN devices within a single room.

As it is not possible to rely on hardware such as network cables (in a LAN) or household wiring (in a dLAN) to control access to a WLAN, wireless networking naturally presents special security challenges. WLANs therefore use a number of security measures, such as a concealed network name, data encryption and access control via the MAC addresses of the network adapters.

2.2.1 Wi-Fi or WLAN?

Wi-Fi is an invented brand name of the Wi-Fi Alliance, a consortium that certifies devices with wireless interfaces. In many countries, Wi-Fi is also used synonymously with WLAN, which if taken strictly, is incorrect, because Wi-Fi designates the wireless standard and WLAN the wireless network.

2.3 What exactly is range+?

Range+ is a technology for devolo dLAN products. Unlike conventional Powerline technology, range+ Technology uses all three lines (neutral, earth wire, phase) of the electrical circuit, making use of the

full physical potential. Thanks to patented signal coupling, data transmission over the mains supply is optimised. This results not only in a more stable Internet connection that is less sensitive to interference, but also increased range.

2.4 What does WiFi Clone mean?

WiFi Clone is a technology for devolo WiFi products that makes it extremely easy to integrate new devices into an existing WiFi network. For this purpose, just plug the corresponding adapter into an available electrical socket and press the PLC button (for older models, the WPS button). The devolo WiFi devices now automatically exchange their WiFi credentials with the existing WiFi router and synchronise SSIDs, keys and any configured settings, such as parental control and tim

2.5 The dLAN 550+ WiFi

The dLAN 550+ WiFi is equipped with

- A PLC button (home icon) with LED status display,
- A WiFi button with LED status display,



The LED status display can be deactivated on the configuration interface of the adapter (see 4.7 System).

- One network jack
- One reset button
- Two internal WiFi antennas
- One integrated electrical socket



Fig. 2 is country-specific

2.5.1 PLC button



This button controls the following functions:

Encrypting the dLAN network

- To encrypt your dLAN network individually, press **each PLC button** on the connected devices for approx. **1 second** – within 2 minutes.
- To remove a dLAN device from your network, press the **PLC button** on the corresponding device **for at least 10 seconds**. For more information, refer to Chapter 3.3 **Connecting the dLAN 550+ WiFi**.

Reading the PLC indicator light

The integrated indicator light (LEDs) shows the dLAN status for the dLAN 550+ WiFi by illuminating and/or flashing:

- *Check whether the adapter is connected to the mains supply correctly and whether the encryption process has been carried out successfully. For more information about this, refer to 3.3 **Connecting the dLAN 550+ WiFi**.*

	PLC LED	Flashing behaviour	Meaning	LED status display (web interface*)
1	Red LED	Lights up steady	Adapter is in the start-up process	Cannot be disabled
2	Red LED	Flashes at intervals of 0.5 sec. (on/off)	No dLAN connection exists	Cannot be disabled
3	Red LED	Flashes at intervals of 2 sec. (on/off)	Data transmission rate not in optimum range *	Can be disabled
4	White LED	Lights up steady	An encrypted dLAN connection exists and the adapter is ready to operate	Can be disabled
5	White LED	Flashes at intervals of 0.5 sec. (on/off)	dLAN encryption being established	Can be disabled
6	White LED	Flashing at intervals of 0.5/50-60 sec. (On/off)	Adapter is in Standby mode	Can be disabled

* Information about the web interface can be found in Chapter **4 Network configuration**.

** Information on improving the transmission rate can be found in Chapter **5.3 Bandwidth optimization**.

***A dLAN adapter switches to standby mode after approximately 10 minutes if no active network device (e.g. computer) is connected to the network interface and the WiFi is switched off. In this mode, the dLAN adapter cannot be accessed over the electrical wiring. As soon as the network device (e.g. computer) connected to the network interface is switched on again, your dLAN adapter can also be accessed over the electrical wiring again.

i Check whether the adapter is connected to the mains supply correctly and whether the pairing operation has been carried out successfully. For more information about this, refer to **3.3 Connecting the dLAN 550+ WiFi**.

2.5.2 WiFi button



The WiFi button controls the following WiFi functions:

WiFi On/Off:

- In the **factory default settings**, the **WiFi** setting is already **enabled** and the WiFi encryption is set to **WPA2**. The WiFi key is the unique key of the dLAN 550+ WiFi. You can find this key on the label on the rear side of the housing.




Fig. 3 WiFi button

- In order to **switch WiFi off**, press and hold the WiFi button **longer than 3 seconds**.
- In order to switch **WiFi back on**, tap the **WiFi button**.

Connecting WiFi devices via WPS

- If the device is still on **factory defaults**, tap the **WiFi button** in order to activate **WPS**.
- If the **WiFi** connection was **switched off** and you would like to activate **WPS**, press the

WiFi button twice; once to switch WiFi on, and again to activate WPS.

- *WPS, developed by the WiFi Alliance, is one of the encryption standards in a WiFi network. The objective of WPS is to make it easier to add devices to an existing network. For more detailed*

information, refer to Chapter 4.4.7 WiFi Protected Setup (WPS).

Reading the WiFi indicator light

The integrated indicator light (LED) shows the WiFi status for the dLAN 550+ WiFi by illuminating and/or flashing:

	WiFi LED	Flashing behaviour	Meaning	LED status display (web interface*)
1	White LED	Flashes at intervals of 0,1 sec. on/5 sec. off	The dLAN adapter is in WPS mode to integrate WiFi-enabled devices via WPS.	Cannot be disabled
2	White LED	Lights up steady	WiFi is switched on and active.	Can be disabled
3	White LED	Off	<p>Status 1: The WiFi LED is switched off and the devolo adapter is still ready for use.</p> <p>Status 2: The WiFi function ist disabled.</p>	Can be disabled

	WiFi LED	Flashing behaviour	Meaning	LED status display (web interface*)
4	White LED	Flashes at intervals of 0.2 sec. (on/off)	Firmware update	Cannot be disabled

* Information about the web interface can be found in Chapter 4 **Network configuration**.

2.5.3 Network jack

A PC or another network device can be connected to the dLAN 550+ WiFi at this port using a standard network cable.

2.5.4 Reset

The **reset** button (next to the network jack) has two different functions:

- **The device restarts** if you press the Reset button **for less than 10 seconds**.
 - To change the configuration of the dLAN 550+ WiFi back to the **factory defaults**, press the **Reset** button for **more than 10 seconds**. Keep in mind that all settings that have already been configured will be lost!
- *You can use a pointed object (such as a paper clip) to press the Reset button.*

2.5.5 WiFi antennas

The internal WiFi antennas are for connecting to other network devices wirelessly.

2.5.6 Integrated electrical socket

To connect other network devices to your mains supply, use the electrical socket of the dLAN 550+ WiFi. The mains filter integrated into the dLAN 550+ WiFi eliminates any noise of connected devices and significantly improves data transmission in the network.

3 Initial use

This chapter covers everything you need to know to set up your dLAN 550+ WiFi. We provide a description of how the device is connected and briefly introduce the included devolo software.

3.1 Package contents

Please ensure that the delivery is complete before beginning with the installation of your dLAN 550+ WiFi.

- **Single Kit:**
 - dLAN 550+ WiFi
 - Hard copy of installation guide
 - CE declaration

or

- **Starter Kit:**
 - dLAN 550+ WiFi
 - dLAN 550 duo+
 - Network cable
 - Hard copy of installation guide
 - CE declaration

devolo AG reserves the right to change the package contents without prior notice.

3.2 System requirements

- Operating systems supported by devolo Cockpit:
 - from Windows 7 (32-bit/64-bit),
 - from Ubuntu 13.10 (32-bit/64-bit),
 - from Mac (OS X 10.9)
- Network connection
 - *Please note that your computer or other device must have a network card or network adapter with a network interface.*

To set up a dLAN network, you need at least two dLAN adapters.

3.3 Connecting the dLAN 550+ WiFi



CAUTION! Damage to the device caused by ambient conditions
Only use device indoors in dry conditions

In the following sections we describe how to connect the dLAN 550+ WiFi and integrate it into the network. We clarify the exact procedures based on potential network scenarios.

- *For the permitted voltage range for operating the device and the power consumption, refer to the label on the rear of the device. For additional technical information on our products, refer to the Service Centre area at www.devolo.com.*

3.3.1 Starter Kit – Setting up a new dLAN network

- Connect the dLAN 550 duo+ to your Internet access device's network jack (e.g. WiFi router).



CAUTION! Tripping hazard

Lay the network cable in a barrier-free manner and ensure that the electrical socket and the connected network devices are easily accessible

- Plug the dLAN 550+ WiFi into a wall socket. As soon as the LED indicator light flashes red at regular intervals of 0.5 sec., the adapter is ready to operate but not yet integrated into the dLAN network.

Connecting the two dLAN 550+ WiFi to a dLAN network

Before you can use the adapter in a dLAN network, first you have to connect it as a network. This is accomplished by using a shared dLAN password. This forms a delimited dLAN network. Shared use of the

dLAN password serves both as access control to the dLAN network as well as the encryption, and thereby the interception protection, of the transmitted data.

The dLAN password can be set in different ways:

dLAN network encryption:

- **dLAN network encryption: at the touch of a button:** First press the PLC button of the **dLAN 550 duo+** for approx. **1 second**, and then **within 2 minutes** press the PLC button of the **dLAN 550+ WiFi** for approx. **1 second**.

or

- **dLAN network encryption by entering the dLAN password in the dLAN:** More information can be found in Chapter **4.5 Powerline**.



As soon as the white LED lights up steady on both devices, your dLAN network is set up and protected from unauthorised access.

3.3.2 Addition – Expanding an additional network

- Plug the dLAN 550+ WiFi into a wall socket. As soon as the LED indicator light flashes red at regular intervals of 0.5 sec., the adapter is ready

to operate but not yet integrated into the dLAN network.

Integrating the dLAN 550+ WiFi into an existing dLAN network

Before you can use the dLAN 550+ WiFi in your dLAN network, first you have to connect it to your existing dLAN devices as a network. This is accomplished by using a shared dLAN password. The dLAN password can be set in different ways:

dLAN network encryption:

- **dLAN network encryption: at the touch of a button:** First press the PLC button on a device in your existing network for approx. **1 second** and **within 2 minutes**, press the PLC button of the new dLAN 550+ WiFi for approx. **1 second**.

or

- **dLAN network encryption by entering the dLAN password in the dLAN:** More information can be found in Chapter **4.5 Powerline**.



As soon as the white LED lights up steady, the new dLAN 550+ WiFi is integrated into your existing, encrypted dLAN network.

Integrating the dLAN 550+ WiFi into an existing WiFi network

- Establish the WiFi connection with your laptop, tablet or smartphone by entering the previously noted WiFi key as the network security key.

To ensure that the dLAN 550+ WiFi has the same WiFi configuration as your WiFi router, you can apply the WiFi access data at the touch of a button using the **WiFi Clone** function. This can be enabled in different ways:

Enabling WiFi Clone:

- Enabling WiFi Clone at the touch of a button: First press the **PLC button** with the **home icon** on the front side of dLAN 550+ WiFi and then press the WPS button of the WiFi router with the access data you want to apply.

or

- **Enabling WiFi Clone via the configuration interface.**

More information about this function can be found in Chapter **WiFi Clone**.




Fig. 4: Setting up the dLAN network

Connecting devices to the WiFi network

- Establish the WiFi connection with your laptop, tablet or smartphone by entering the previously noted WiFi key as the network security key.

3.4 Installation of devolo software

Installing devolo Cockpit software

devolo Cockpit finds all accessible dLAN adapters in your dLAN network, displays information about these devices and encrypts your dLAN network individually. You can use the software to navigate to the integrated web interface.

Operating systems supported by devolo Cockpit (Version 5.0 or later):

- from Windows 7 (32-bit/64-bit) or later,
 - from Ubuntu 13.10 (32-bit/64-bit),
 - from Mac (OS X 10.9)
- You can find the product manual, software and additional information on devolo Cockpit online at www.devolo.com/cockpit.

Downloading the devolo Home Network App

The devolo Home Network App is devolo's **free app** also for checking and configuring WiFi, Magic and LAN connections for the dLAN adapter (using a smartphone or tablet). The smartphone or tablet connects to the dLAN adapter at home over Wi-Fi.

- ① Download the devolo Home Network App to your smartphone or tablet computer from the corresponding store.
 - ② The devolo Home Network App is placed in your smartphone's or tablet's app list as usual. Tapping on the devolo Home Network App icon brings you to the start menu.
- *You can find more information about the devolo Home Network App online at www.devolo.com/devolo-app.*

3.5 Removing the adapter from the network

To remove the dLAN 550+ WiFi device from an existing network, press the PLC button with the home icon on the corresponding adapter for **at least 10 seconds**. The device will be assigned a new randomly generated password and will thus no longer be able to access the network. To integrate the device into a different network, follow the steps described above, depending on whether you are setting up a new network or adding the device to an existing one.

4 Network configuration

The dLAN 550+ WiFi has a built-in web interface that can be called up using a standard web browser. All settings for operating the device can be modified here.

4.1 Calling up the built-in web interface

You can access the built-in online web interface for the dLAN 550+ WiFi in different ways:

- Using the **devolo Home Network App** on your smartphone or tablet, you can access the device's web interface by going to the devolo Home Network App **overview page** and tapping on the **gear/arrow**.

i You can find more information on devolo Home Network App in Chapter 3.4 **Installation of devolo software**.

or

- Using the **Cockpit software** under **Start → All Programs → devolo → devolo Cockpit**, you can get to the device's web interface by clicking on the corresponding tab for the dLAN 550+ WiFi. Then the program determines

the current IP address and starts the configuration in the web browser.

i *By default, the web interface will open directly. However, if an access password has been set via the option **System → Management**, you have to enter that password first. Read more about this under **4.7 System**.*


4.2 General information about the menu

All menu functions are described in the corresponding interface as well as in the associated chapter in the manual. The sequence of the description in the manual follows the structure of the menu. The figures for the device interface serve as examples.

Logging in

The web interface is not password protected. Assigning a login password is mandatory when logging in for the first time to prevent unauthorised access by third parties.

Enter your existing password each time you login again and confirm by pressing **Log in**.



Please log in with your password!

Password:

Logging out




Log out of the web interface by clicking **Log out**.

Language selection



Select the desired language in the language selection list.

The central areas of the web interface and their sub-categories are listed on the left edge. Click the entry for an area to move directly into it.



Making changes

Once you make a change, two icons are shown on the corresponding menu page:

- **Disk** icon: Your settings are being saved.
- **X** icon: The operation is being cancelled. Your settings are not being saved.

Required fields

Fields with a red border are required fields. This means entries must be made in these fields to continue with the configuration.

Help text blank fields

Fields that have not been filled in yet contain greyed out help text, which indicates the required con-

tent for the field. This help text disappears immediately once content has been entered.

Default settings

Some fields contain default settings which ensure the greatest amount of compatibility and ease of use. Default settings are identified with an * in drop-down menus.

Default settings can of course be replaced with customised information.

Recommended settings

Some fields include recommended settings.

Recommended settings can of course be replaced with customised information.

Tables

You can make changes within a table by clicking the corresponding table row in **Time Control** and **Parental Control**. In edit mode, the corresponding table rows have a blue background. In edit mode, the corresponding table rows have a blue background.

Invalid entries

Entry errors are either highlighted by a red border or error messages are shown.

Buttons

Click the **Disk** icon to save the settings for the respective web interface area.

Click the **X** icon or use the **Menu path** above the buttons to exit the respective web interface area.

Click the **Recycle bin** icon to delete an entry.

Click the **Arrow** icon to refresh a list.

4.3 Overview

The **Overview** area shows the status of the dLAN 550+ WiFi and the connected LAN, PLC and WiFi devices.

System

You can see status information for your device here.

System	
Information	
Name:	devolo-183
Serial number:	1701120520001183
Firmware version:	5.0.0 (2018-08-06)

WiFi

You can view status information for a wireless network such as frequency channels in use, SSIDs in use and connected WiFi devices here.

WiFi	
2.4 GHz	
Current channel:	11 (auto)
Enabled SSIDs:	devolo-183
Connected WiFi clients:	0

Powerline

You can view status information for your dLAN network and connected devices here.

Powerline	
Local Device	
Verschlüsselung:	Secured
Network	
Connected clients:	4

LAN

You can see status information for a cable-based network such as protocol information or the connection speed of both Ethernet ports, etc. here.

Port 1:	100 Mbps
Ethernet:	B8:BE:F4:00:04:B2

IPv4

Protocol:	DHCP
Address:	192.168.178.97
Subnet mask:	255.255.255.0
Default gateway:	192.168.178.1
DNS server:	192.168.178.1

4.4 WiFi




Make all changes to your wireless network in the **WiFi** area.

 WiFi / Status









WiFi Clients



Status	MAC Address	Manufacturer	Frequency band	Network name	Tx rate (Mbps)	Rx rate (Mbps)	Since
	D0:D2:80:2C:3E:C8	Apple, Inc.	2.4 GHz	devolo-050	n/a	n/a	0 Tage, 02:30:15
	A4:DB:30:FF:9A:82	Liteon Technology...	2.4 GHz	devolo-050	n/a	n/a	0 Tage, 01:02:26
	E4:F0:42:18:CD:BD	Google, Inc.	5 GHz	devolo-050	263	390	0 Tage, 02:09:37

WiFi Network



Active	Network name	Encryption	Frequency band	Current channel	Connected clients
	devolo-050	WPA2 Personal	2.4 GHz	1 (auto)	0
	devolo-050	WPA2 Personal	2.4 GHz	1 (auto)	0
	devolo-050	WPA2 Personal	5 GHz	100 (auto)	1
	devolo-guest-050	WPA2 Personal	5 GHz	100 (auto)	0
	devolo-guest-050	WPA2 Personal	2.4 GHz	1 (auto)	0
	devolo-guest-050	WPA2 Personal	5 GHz	100 (auto)	0

4.4.1 Status

You can see the current status of your WiFi network configuration here, e.g. the connected WiFi stations, the MAC address, the selected frequency band, the SSID, the transfer rates and the connection duration.

4.4.2 WiFi networks

WiFi on/off

If you want to operate the adapter exclusively as a simple dLAN device via the built-in Ethernet connection, you can completely shut off the WiFi function.



Keep in mind that after saving this setting, you will be disconnected from any existing wireless connection to the dLAN 550+ WiFi. In this case, configure the device over Ethernet.

For operation as a WiFi access point, configure the WiFi parameters for your wireless network as follows.

on off

2.4 GHz

2.4 GHz network name: devolo1

Channel: Auto

Mode: 802.11b/g/n

Hide SSID:

Encryption:

WPA2 WPA/WPA2 none

.....



One of the following key is required: a passphrase with a length of 8 to 63 characters or a pre-shared key with a length of 64 characters.

Network name

The **network name (SSID)** determines the name of your wireless network. You can see this name when logging onto the WiFi, allowing you to identify the correct WiFi network.

Channel

For operation as an access point, a (transmission) channel must be specified. There are 13 channels available. We recommend keeping the default setting **Auto**, since in this setting the dLAN 550+ WiFi selects the channel regularly and independently. If no stations are connected, the device automatically selects a channel every 2 hours.

Mode

In the **Mode** field, select the desired WiFi communication standard.

Hide SSID:

The **SSID** specifies the name of your wireless network. You can see this name when logging onto the WiFi, allowing you to identify the correct subnet.

If the **Hide SSID** option is disabled, your network name is visible. If this option is disabled, potential network users must know the exact SSID and enter it manually to be able to set up a connection.

i *Some WiFi stations have difficulty connecting to hidden wireless networks. If the connection to a hidden SSID poses problems, first try to set*

up the connection with a visible SSID and only then try to hide it.

Security

The **WPA2 Personal (WiFi Protected Access)** security standard is available for securing data transmission in your wireless network. This method allows for individualised keys consisting of **letters and numbers and the depicted special characters with a length of up to 63 characters**. You can simply enter them into the **Key** field via the keyboard.

In addition, the dLAN also supports the **WPA/WPA2** encryption key. As a central authentication and accounting server, a RADIUS server handles the registration and management of user information for multiple WiFi access points.

4.4.3 Guest network

If you have friends or acquaintances visiting and you want to provide them with Internet access but without giving away the password for your WiFi, you can set up a separate guest account in addition to the main Internet connection. The guest ac-


count can have its own network name, time limit and WiFi password. This way your visitors can browse the Internet without having access to your local network.

Enable

The guest network does only allow access to the internet.


Network name:

Encryption: WPA2 WPA/WPA2 none



One of the following key is required: a passphrase with a length of 8 to 63 characters or a pre-shared key with a length of 64 characters.

The QR-Code gives you easy access to the guest network using mobile devices such as smartphones or tablets. While scanning the QR-code the credentials for the guest network will be transferred to your mobile device.



Automatic Shutoff

Enable

Select a time period. The guest WiFi network is automatically switched off after this period has elapsed.

Selected time period:

5 h 

To set up a guest account, activate the **Enable** option.

The guest account has an **Automatic shutoff** feature. This feature automatically disables the guest network once the selected time period ends.

You can use the **Enable** option to activate the shut-off feature.

- *You can also enable or disable the guest account in the **devolo Home Network App** using the **Guest account** button.*

Network name

Define the name of the guest network in the **Network name** field.

Key

You should also encrypt the guest account to prevent anyone in signal range from intruding into your network and, for example, sharing your Internet connection. The **WPA/WPA2 (WiFi Protected Access)** security standard is available for this.

This method allows for individualised keys consisting of **letters and numbers with a length of up to 63 characters**. You can simply enter them via the keyboard.

To do so, enter a corresponding number of characters into the **Key** field.

QR code

Using the QR code, you can conveniently set up the connection to the guest network for mobile devices. Scanning the QR code automatically transfers the credentials for the guest network to the respective mobile device. The QR code is visible only if the guest network has been enabled.

4.4.4 Mesh

Mesh

All devolo WiFi adapters offer mesh WiFi, which entails completely new and improved WiFi functions:

- **Fast roaming** (IEEE 802.11r) streamlines the registration process for WiFi end devices, such as smartphones or tablets, when switching to another WiFi hotspot.

- *The feature **Fast roaming** is not compatible with all WiFi clients. If there will be connection problems with one of your devices, please deactivate these option.*

In factory default condition of the dLAN 550+ WiFi **Fast roaming** is turned off by default.

- In addition, the new **air-time fairness** feature processes the requests of high-speed WiFi clients at higher priority. This prevents older devices, which may require more time for a download, from creating WiFi bottlenecks.
- **Band steering** ensures that all WiFi stations automatically switch to the optimum fre-

quency band in order to use the best WiFi connection at all times.

In order to turn the mesh functions on, activate the **Enable** option.

The mesh function of the dLAN 550+ WiFi is switched on by default.

Mesh WiFi

Enabling the Mesh functionality features will optimize your inhome WiFi network experience while using your mobile devices. Inhome roaming solves your sticky client problem, Band Steering and Dynamic Frequency Selection provides WiFi access even with many clients and Airtime Fairness optimizes your bandwidth.

Enable

Features

IEEE 802.11r (also called "Fast Roaming") accelerates the login of a WiFi device to this WiFi access point. Requirement: The device was already connected to another WiFi access point with 802.11r enabled, identical network name (SSID), and identical encryption. Unfortunately, 802.11r is not compatible with every WiFi device. If you experience problems with any of your devices, please disable this option.

IEEE 802.11r

WiFi Clone

WiFi Clone makes it possible to simply copy the WiFi configuration data of an existing WiFi access point (e.g. your WiFi router) to all WiFi access points (Single SSID). Start the procedure with the

Start setup option and then press the WPS button of the device with the WiFi access data (SSID and WiFi password) to be applied.

WiFi Clone

WiFi Clone allows you to apply the WiFi access data (network name and WiFi password) of another WiFi access point to this device automatically. This requires that you start the configuration process and then press the WPS button on the device containing the WiFi access data (SSID and WiFi password) to be applied.

Start Configuration

4.4.5 Schedule control

The **Schedule control** area lets you define when and if your WiFi is switched on and off.

WiFi schedule settings

WiFi schedule control

Enable


WiFi convenience function

Enable

When the WiFi convenience function is activated, the wireless network is not switched off until the last WiFi device has logged off from your access point.

Please note that many tablets/smartphones maintain their WiFi connection indefinitely!

Overview of the wifi schedule settings



Configuration

Here you can define the time intervals for when you want your WiFi to be activated.



Interval	From	to
Mon-Fri	18:30	24:00

Enabling WiFi schedule control

In order to be able to use time control, activate the **Enable** option.

Configuration

You can define multiple time periods during which your wireless network is to be enabled for each weekday. Then the time control automatically switches the wireless network on or off.

Automatic disconnection

If you enable the **Automatic disconnection** option, the wireless network is not switched off until the last station has logged off.

- *Manually switching the device on and off (using a button) always has priority over automatic time control. The configured time control then takes effect automatically during the next defined time period.*

4.4.6 Parental control

You can regulate WiFi access for specific devices based on time using this function. For instance, to prevent your children from using the Internet excessively, you can define how long they may use the WiFi per day. Synchronisation with an (Internet) time server is necessary to be able to use

the parental control. In this case, the time server (**System** → **Management** → **Time Server (NTP)**) for the dLAN 550+ WiFi ac has to be enabled and an active Internet connection is also required.

- *The time server pool.ntp.org is enabled by default. You can find more information in Chapter 4.7.2 Management.*


If you would like to set up a **time quota** (usage time in hours) or a **time period** (active from/to), activate the **Enable** option. Now enter the MAC addresses of the devices you want to set up parental control for.

Under **Type**, define either a **time quota** (time limit) or a **time period** for when you want the MAC addresses entered to receive Internet access. Under **Select interval**, select the desired time frame.

Parental control

Enable

A1:55:EE:5E:14:8E



Configuration

Please note that WiFi schedule Settings have precedence over these settings!

You can limit access to certain Wi-Fi devices by the MAC address. Please define the time periods during which Wi-Fi access is allowed.



MAC address	Type			
A1:55:EE:5E:14:8E	Interval	Sat+Sun	10:00	20:00
A1:55:EE:5E:14:8E	Interval	Mon-Fri	18:15	20:00

Setting the time quota

Under **Time Quota**, the time limit can be selected.

Confirm your settings by clicking the **Disk** icon.

Setting the time period

Under **Time Period**, the desired time period can be selected. After entering the interval, enter the desired start and end times in hour and minute format.

Confirm your settings by clicking the **Disk** icon.

If you want to delete a time quota (time limit) or a time period from the list, click/touch the **dustbin** icon.

4.4.7 WiFi Protected Setup (WPS)

WiFi Protected Setup (WPS) is one of the international encryption standards developed by the WiFi Alliance for easily and quickly setting up a secure wireless network. The encryption keys of the respective WiFi devices are transmitted automatically and continuously to the other WiFi device(s) in the wireless network.

Enabling WPS encryption

In order to be able to use WPS encryption, activate the **Enable** option.

WiFi / WPS 🇬🇧

WiFi Protected Setup (WPS) - Configuration

Enable

Network name:

WPS Mode: **WPS Pushbutton**

Add devices to the WiFi network using the soft push button.
Now press the WPS button on the device being added to your WiFi network.

WPS PIN

Add devices to the WiFi network using your PIN.
Enter the PIN of the device to be added to your WiFi network.

76 s

WPS Pushbutton is active...

The dLAN 550+ WiFi offers two different variants for transmitting these encryption keys:

WPS using WPS pushbutton

- 1 Start the encryption process on the dLAN 550+ WiFi
 - By pressing the **WiFi button** on the **front side of the device** or
 - By pressing the corresponding **Start** button on the user interface under **WiFi → WPS Pushbutton**.
- 2 Then either press the WPS key of the WiFi device you are adding or enable the WPS mechanism in the WiFi settings of the WiFi device. Now the devices exchange their encryption keys and establish a secure WiFi connection. The WiFi LED on the front panel indicates the synchronisation process by flashing.

WPS via PIN

To interconnect WiFi devices in your wireless network securely using a PIN variant, go to the web interface and, under **WiFi → WPS → WPS PIN**, enter the WPS PIN generated by your Android smartphone or tablet and start the encryption process by pressing the corresponding **Start** button.

Use of the **WPS** method implies the use of the **WPA/WPA2** encryption standard. Therefore take note of the following automatic settings:

- If under **WiFi → WiFi networks**, the **No encryption** option is selected in advance, **WPA2** is set automatically. The newly generated password is displayed under **WiFi → WiFi networks** in the **Key** field.
- If under **WiFi → WiFi networks**, the **WPA/WPA2** option is selected in advance, this setting **remains** with the previously assigned password.

4.4.8 Neighbour networks

The **Neighbour networks** area displays visible wireless networks in your surroundings.

Network name	Channel	Signal quality (%)
devolo-183	100	94
DVT-3490-5	124	94
devolo-183	11	94
NETGEAR70_jonas_r	6	94
Loft TV.b	6	94
DVT-3490-2	1	94
devilo24	1	94
devolo-159	1	94
ASUS_7437b8fde68	9	94
NETGEAR-2	2	94

4.5 Powerline

Make all changes to your PLC network in the **Powerline** area.


The connected dLAN devices are displayed with detailed basic information such as the MAC


address, local or network connectivity, functionality as a centralised coordinator and the transmission rates.

Encryption

Encryption: Secured

Connected Powerline devices



AVLN	Device Name	MAC address	Connection	Central Coordinator	Tx rate (Mbps)	Rx rate (Mbps)
1	devolo-618	F4:06:8D:4F:68:27	remote		219	247
1	Geraet ICP	30:D3:2D:26:E8:A3	local		-	-

In a dLAN network, all connected components must use the same password. This can be assigned in different ways:

- Using **devolo Cockpit** or the **devolo Home Network App** (see Chapter 3.4 **Installation of devolo software**),
- Only using the **PLC button** (see Chapter 2.5.1 **PLC button** and 3.3 **Connecting the dLAN 550+ WiFi**)

- Using the web interface, in the **PLC** menu **Powerline** → **Settings**:

Powerline Password

You can also assign your network a custom PLC password you pick yourself. Enter this password for each dLAN adapter in the **Network password** field and confirm your settings by clicking the **Disk** icon.

Note that the custom password is not assigned to the whole PLC network automatically. Instead, you must assign it separately to each of your dLAN adapters.

Powerline network Mode

There are two logical operating modes for dLANs. dLANs are set up in peer-to-peer operating mode by default. Alternatively, there is also the MDU operating mode.

In the dLAN peer-to-peer [P2P] operating mode, every dLAN device on the dLAN can communicate with every other dLAN device on the same dLAN directly. Within a P2P network, all dLAN devices are equal to each another in the hierarchy. In order to coordinate the communication between the individual end points of the network, the dLAN devices in the P2P network automatically determine the dLAN device which is easiest for all devices in this

same dLAN network to reach. This device takes on the role of the Central Coordinator [CCo], which ensures efficient communication between the individual end points [peers] in the P2P network.

In the dLAN operating mode known as "Multiple Dwelling Unit" [MDU], one or more dLAN devices are assigned as 'slaves' to a single dLAN device as 'master', and together they form a shared, logical network segment. Each of these MDU dLAN segments always contains exactly one master and 1 to 63 slaves which are assigned to the master. In MDU operating mode, direct data communication is only between the slave and its master ["peer isolation"], and never from slave to slave.

Powerline Password

Enter the Powerline network password needed for your device to access your Powerline network. All devices that are part of a Powerline network must use the same Powerline network password.

Password: 

Powerline Network Mode

Choose the network mode of your device.

Network Mode: ▼

4.5.1 Add device

Using the encryption (PLC) button

If you would like to manually add a new dLAN device, press the encryption button within 2 minutes on the device which you want to join your Powerline network and confirm with **Start configuration**.

Via security ID

If you would like to manually add a new dLAN device, provide its security ID and confirm with **Start configuration**.

Using the encryption button

Use the encryption button to allow the device to join the Powerline network. Press the encryption button within 2 minutes on the device which you want to join your Powerline network! Afterwards, click the "Start configuration" button.

Via security ID

Here you can add a new Powerline device to your network. First, enter the security ID printed on the rear side, plug the device into a power outlet and then confirm by clicking "Start configuration".

The security ID consists of four groups, each with four capital letters, separated by hyphens.

Security ID: ---

4.6 LAN

You make changes to the network settings in the **LAN** area.

Ethernet

Port 1:	100 Mbps
Ethernet:	B8:BE:F4:00:04:B2

IPv4

Protocol:	DHCP
Address:	192.168.178.97
Subnet mask:	255.255.255.0
Default gateway:	192.168.178.1
DNS server:	192.168.178.1

4.6.1 Status

You can see the current LAN status of the dLAN adapters here. The **Ethernet** area shows the network devices connected to the network connector **Port 1** (e.g. PC).

IPv4

Depending on how the dLAN 550+ WiFi is connected to the Internet, current network infor-

mation is displayed, such as **Address**, **Subnet mask**, **Standard gateway** and **DNS server**.

4.6.2 IPv4 configuration

In the factory default settings, only the **Retrieve network settings from a DHCP server** option for **IPv4** is enabled. This means that the IPv4 address is retrieved automatically from a DHCP server. The currently assigned network data are visible (greyed out).

If a DHCP server is already present on the network for assigning IP addresses (e.g. your Internet router), you should leave the **Retrieve network settings from a DHCP server** option enabled so that the dLAN 550+ WiFi automatically receives an address from it.

If you want to assign a static IP address, make entries accordingly for the **Address**, **Subnet mask**, **Default gateway** and **DNS server** fields.

Confirm your settings by clicking the **Disk** icon.

Then, restart the dLAN adapter (see Chapter **4.7.3 Configuration**) to ensure that your changes take effect.

4.7 System

In the **System** area, you can configure the settings for security and other dLAN adapter device functions.

Date and Time

Local time:	10.09.2018 14:51
Time zone:	Europe/Aachen
Time server 1:	europe.pool.ntp.org

MAC Addresses

Ethernet	30:D3:2D:AF:8B:B9
----------	-------------------

LEDs

WiFi LED:	Enabled
Powerline LED:	Enabled

Buttons

PLC button:	Enabled
WiFi button:	Enabled

4.7.1 Status

Here you can view the most important information on the dLAN adapter, including the current date and time, time zone, MAC address of the adapter, status of the WiFi and Powerline LEDs and the two operating buttons (PLC button and WiFi button).

4.7.2 Management

System information lets you enter user-defined names in the **Device name (hostname)** and **Device location** fields. Both pieces of information are particularly helpful if multiple dLAN adapters are to be used and identified in the network.

Under **Change access password**, a login password can be set for accessing the web interface.

By default, the built-in web interface of the dLAN 550+ WiFi is not protected by a password. We recommend assigning a password when the installation of the dLAN 550+ WiFi is complete to protect it against tampering by third parties.

- *To do so, enter the desired new password twice. Now the web interface is protected against unauthorised access with your custom password!*

In **Power Management**, you can enable Power-save mode and Standby mode on the dLAN 550+ WiFi.

If **Powersave** mode has been enabled, the dLAN 550+ WiFi switches to PowerSave mode automatically whenever reduced data transmission over ethernet is detected.

- *The latency (time for transmitting a data packet) may be negatively affected if very slow data transmission is detected.*

If **Standby** mode is enabled, the dLAN 550+ WiFi automatically switches to Standby mode if no ethernet connection has been enabled, i.e. if no network device (e.g. computer) is switched on and connected to the network interface and if WiFi is disabled.

In this mode, the dLAN 550+ WiFi is not accessible over the Powerline network. As soon as the network device (e.g. computer) connected to the network interface is switched on again, your adapter can also be accessed over the electrical wiring again.

Powersave mode is disabled in the dLAN 550+ WiFi factory default settings.

Standby mode is enabled in the dLAN 550+ WiFi factory default condition.

The **LED settings** let you disable the LED status display of the **WiFi** and **Powerline** LEDs.

An error status is indicated by corresponding flashing behaviour regardless of this setting (see Chapter **Reading the PLC indicator light**).

- *For information on the LED behaviour of the dLAN adapter in standby mode, refer to Chapter **Reading the PLC indicator light**.*

You can completely disable the **operating buttons** on the dLAN adapter in order to protect yourself against possible changes. Simply disable the **Enable PLC button** or **Enable WiFi button** option.

The operating buttons are enabled in the dLAN 550+ WiFi factory default settings.

Under **Time zone**, you can select the current time zone, e.g. Europe/Berlin. The **Time server (NTP)** option lets you specify a time server. A time server is a server on the Internet whose task consists of providing the exact time. Most time servers are coupled with a radio clock. Select your time zone and time server; the dLAN 550+ WiFi automatically

switches between standard time and summer time.

4.7.3 Configuration

Saving the device configuration

To save the enabled configuration to your computer as a file, select the corresponding button in the **System → Configuration → Save Configuration to File** area. The system starts downloading the current device configuration.

Restoring the device configuration

An existing configuration file can be sent to the dLAN 550+ WiFi in the **System → Configuration** area and enabled there. Select a suitable file via the **Select file ...** button and start the operation by clicking the **Restore** button.

Resetting the device configuration

The dLAN 550+ WiFi is reset to the original factory defaults in the **System → Configuration** area with the **Reset Configuration** option.

I *Doing so causes you to lose your personal WiFi and PLC settings. The last-assigned passwords for the dLAN 550+ WiFi are also reset.*

For backup purposes, all active configuration settings can be transmitted to your computer, stored there as a file and reloaded into the dLAN 550+ WiFi. This function can be useful for creating a variety of configurations that will let you quickly and easily set up the device for use in different network environments.

Reboot device

In order to reboot the dLAN 550+ WiFi, select the **Reboot** button in the **System → Configuration** area.

4.7.4 Firmware

Current firmware

The currently installed firmware of the dLAN 550+ WiFi is displayed here.

Download updated firmware

The firmware of the dLAN 550+ WiFi includes the software for operating the device. If necessary, devolo offers new versions on the Internet as a file download, for example to modify existing functions.

- 1 In order to update the firmware, click on the setting **here**. The link takes you to the devolo website where you can download the appropriate file for the dLAN 550+ WiFi to your computer.
- 2 Then, navigate to the **System → Firmware → Update firmware** area. Click **Browse ...** and select the downloaded file.
- 3 Confirm the update procedure with **Update firmware**. After a successful update, the dLAN 550+ WiFi restarts automatically.



Ensure that the update procedure is not interrupted.

Searching for and updating firmware automatically

The adapter can also look for up-to-date firmware automatically. To do this, enable the **Automatically search for updates** option.

- *The dLAN 550+ WiFi lets you know when a new firmware version becomes available. The option is enabled by default.*

The **Automatic Update** option allows the adapter to automatically install the firmware it has found.

4.7.5 Config Sync

Config Sync allows settings to be configured uniformly for all devolo dLAN devices in the network. This includes the following settings e.g.:

- WiFi network
- Guest network
- Mesh WiFi
- Time control and time server settings.

In order to switch Config Sync on, activate the **Enable** option.

- *Please note that the WiFi is always switched on or off for the entire network. Therefore, stop Config Sync first on a device that you want to configure or switch separately.*

5 Appendix

5.1 Frequency range and transmitting power

Frequency range	2.4 GHz
IEEE standard	802.11 b 802.11 g 802.11 n
Indoor frequency range	–
Indoor & outdoor frequency range	2399.5 – 2484.5 MHz
Channel bandwidth	20 MHz (802.11 b/g) 20, 40 MHz (802.11 n)
Max. indoor transmission power (EIRP)	100 mW / 20 dBm
Max. transmitting power	100 mW / 20 dBm

5.2 Channels and carrier frequencies

Channel	Carrier frequency
1	2412 MHz
2	2417 MHz
3	2422 MHz
4	2427 MHz
5	2432 MHz
6	2437 MHz
7	2442 MHz
8	2447 MHz
9	2452 MHz
10	2457 MHz
11	2462 MHz
12	2467 MHz
13	2472 MHz

5.3 Bandwidth optimization

To significantly improve the transmission capacity of the network, we recommend that you comply with the following "connection rules":

- Plug the dLAN 550+ WiFi directly into a wall socket. Avoid using power strips. This may impair the transmission of the PLC signals.
- If there are several sockets in the wall directly next to each other, they behave like a power strip. Individual sockets are optimal.




Fig. 5: Bandwidth optimization

5.4 Disposal of old devices

To be used in the countries of the European Union and other European countries with a separate collecting system:



The icon with crossed-out wastebasket on the device means that this product is an electrical or electronic device that falls within the scope of application of the European Community WEEE Directive. These types of devices may no longer be disposed of with household waste. Rather they can be given to a municipal collection point free of charge. Contact your municipal government to find out the address and hours of the nearest collection point.

5.5 Warranty conditions

If your devolo device is found to be defective during initial installation or within the warranty period, please contact the vendor who sold you the product. The vendor will take care of the repair or warranty claim for you. The complete warranty conditions can be found at www.devolo.com/warranty.

Index

A

Authentication and accounting server 28

C

Config Sync 48

D

Default WiFi key 14

devolo app 20

devolo Cockpit 20

devolo software 20

DHCP server 44

Disposal of old devices 50

I

Intended use 6

IPv4 44

L

LAN (network connection) 16

LED status display 12

Login password 22

O

Operating buttons 46

P

Package contents 17

R

Reset 16

S

Safety notes 7

SSID 28

System requirements 17

T

Time server 46

W

WiFi antenna 16

WiFi key 14

WPA 30

WPA/WPA2 28

WPA2 30